



Installation on a 64-Gallon Toter® Trash Can

We recommend installing the Strong Strap as shown in the image to the left. Please follow the steps listed in the *Quick Start Guide* and view our can-specific recommendations below.

IMPORTANT: It may seem as though there isn't enough room for the anchor and cap to fit as shown, but it is possible if you follow the steps below.



OVERVIEW OF HOW THE PARTS WILL LOOK

Tip #1 Center the Anchor In the Upper Section

Install the anchor directly in the middle of the juttred out upper section, as shown above.

Tip #2 Put the Cap In Place Before Screwing the Anchor Completely In.

First, when drilling into the can, stop just as the tip of the screw breaks through the wall. Next, place the cap on the inside (as shown below) and then finish screwing the anchor in.

